

Head Lite™ Glow Plug Igniter

- Spring loaded connector locks on glow plug
- Fits all standard glow plugs

Instructions

Install a Sub-C or C NiCad battery by pushing the positive end of the battery all the way into the retaining cup and tightening the set screw. Make sure the set screw makes contact with the battery's outer steel shell. Install yellow cover. Charge 12-14 hours before initial using an M023 1.5V charger or equivalent.

Operation

Place over glow plug, push down, turn clockwise and release to lock on. Start engine. To remove push down and turn counter clockwise.

Safety

Do not short circuit!
Cover end with PVC cap when not in use.

Maintenance

Clean occasionally with WD-40 or alcohol.

