

Ball Connector With Locking Sleeve

Instructions:

- Thread a 2-56 rod or coupler 1/4" into ball joint socket. This will leave 5/64" for adjustment each way.
- Slide sleeve back and put the socket onto the ball.
- When the sleeve is released, it will lock the socket on the ball.

